

## SOFAS

Style	Length	Depth	Arm Ht.	Back Ht.	COM
-------	--------	-------	---------	----------	-----

### *Rutzen Series*

#### 9811 Series

9881 Chair	37"	39"	24"	38"	7
9882 Loveseat	58"	39"	24"	38"	11
9883 Sofa	85"	39"	24"	38"	13
9880C Chaise Add-on	30"	24"	--	19"	6

Style	Length	Depth	Arm Ht.	Back Ht.	COM
-------	--------	-------	---------	----------	-----

### *Pendleton*

#### 7640 Series

7641 Chair	37"	37"	26"	38"	9
7642 Loveseat	63"	37"	26"	38"	13
7643 Sofa	78"	37"	26"	38"	17

Style	Length	Depth	Arm Ht.	Back Ht.	COM
-------	--------	-------	---------	----------	-----

### *Holman*

#### 2060 Series

2061 Chair	32"	36"	25"	37"	
2063 Sofa	83"	36"	25"	37"	

Style	Length	Depth	Arm Ht.	Back Ht.	COM
-------	--------	-------	---------	----------	-----

### *Spencer*

#### 6890 Series

6891 Chair	38"	36"	26"	36"	7
6892 Loveseat	63"	36"	26"	36"	11
6893 Sofa	81"	36"	26"	36"	13
6895 Queen Sleeper	87"	36"	26"	36"	13
6894 Full Sleeper	78"	36"	26"	36"	12

## SOFAS

Style	Length	Depth	Arm Ht.	Back Ht.	COM
-------	--------	-------	---------	----------	-----

### *Patterson*

#### 3650 Series

3651 Chair	41"	36"	29"	37"	8
3652 Loveseat	63"	36"	29"	37"	12
3653 Sofa	86"	36"	29"	37"	14

Style	Length	Depth	Arm Ht.	Back Ht.	COM
-------	--------	-------	---------	----------	-----

### *Fairmont*

#### 3410 Series

3411 Chair	33"	36"	25"	36"	7
3412 Loveseat	57"	36"	25"	36"	12
3413 (2) Cushion Sofa	81"	36"	25"	36"	14
34133 (3) Cushion Sofa	81"	36"	25"	36"	15

Style	Length	Depth	Arm Ht.	Back Ht.	COM
-------	--------	-------	---------	----------	-----

### *Woodland*

#### 2880 Series

2881 Chair	55"	39"	27"	35"	10
2882 Loveseat	72"	39"	27"	35"	14
2883 Sofa	93"	39"	27"	35"	16

Style	Length	Depth	Arm Ht.	Back Ht.	COM
-------	--------	-------	---------	----------	-----

### *Tomlinson*

#### 2140 Series

0820 Ottoman	31"	25"	--	16"	4
214130 Oversized Chair	47"	37"	27"	36"	9
2141 Chair	40"	37"	27"	36"	8
2142 Loveseat	63"	37"	27"	36"	13
2144 Full Sleeper	78"	37"	24"	36"	14
2145 Queen Sleeper	87"	37"	27"	36"	15
2143 Sofa	87"	37"	27"	36"	15

## SOFAS

Style	Length	Depth	Arm Ht.	Back Ht.	COM
<b>Shannon</b>					
9580 Series					
9581 Chair	40"	37"	30"	36"	7
9582 Loveseat	60"	37"	30"	36"	11
95833 3-CushionSofa	84"	37"	30"	36"	14
9583 Sofa	84"	37"	30"	36"	13

Style	Length	Depth	Arm Ht.	Back Ht.	COM
<b>Sharon</b>					
9530 Series					
9531 Chair	41"	38"	28"	36"	8
9532 Loveseat	65"	38"	28"	36"	13
9533 Sofa	89"	38"	28"	36"	14
9935 Queen Sleeper	84"	38"	28"	36"	14

Style	Length	Depth	Arm Ht.	Back Ht.	COM
<b>Odessa</b>					
3140 Series					
0314 Ottoman	48"	25"	--	18"	7
3141 Oversized Chair	61"	44"	25"	31"	12
3142 Loveseat	69"	44"	25"	31"	13
3143 Sofa	96"	44"	25"	31"	19

Style	Length	Depth	Arm Ht.	Back Ht.	COM
<b>Classic</b>					
5890 Series					
0589 Ottoman	24"	18"	--	17.5"	
5891 Chair	38"	36"	24"	35"	7
5892 Loveseat	62"	36"	24"	35"	10
5894 Full Sleeper	74"	36"	24"	35"	11
5895 Queen Sleeper	81"	36"	24"	35"	12
5893 Sofa	81"	36"	24"	35"	12

## SOFAS

<u>Style</u>	<u>Length</u>	<u>Depth</u>	<u>Arm Ht.</u>	<u>Back Ht.</u>	<u>COM</u>
<b><i>Morgan</i></b>					
8400 Series					
0820 Ottoman	31"	25"	--	17"	4
8401 Chair	36"	37"	27"	36"	8
8402 Loveseat	59"	37"	27"	36"	13
8403 Sofa	82"	37"	27"	36"	16

<u>Style</u>	<u>Length</u>	<u>Depth</u>	<u>Arm Ht.</u>	<u>Back Ht.</u>	<u>COM</u>
<b><i>Harmony</i></b>					
9780 Series					
9781 Chair	48"	38"	27"	35"	
9782 Loveseat	72"	38"	27"	35"	
9783 Sofa	87"	38"	27"	35"	

<u>Style</u>	<u>Length</u>	<u>Depth</u>	<u>Arm Ht.</u>	<u>Back Ht.</u>	<u>COM</u>
<b><i>Aberdeen</i></b>					
8220 Series					
0820 Ottoman	31"	25"	--	17"	4
8221 Chair	49"	36"	28"(F), 31"(B)	36"	8
8222 Loveseat	78"	36"	28"(F), 31"(B)	36"	13
8223 Sofa	91"	36"	28"(F), 31"(B)	36"	16
8225 Queen Sleeper	91"	36"	28"(F), 31"(B)	36"	16

<u>Style</u>	<u>Length</u>	<u>Depth</u>	<u>Arm Ht.</u>	<u>Back Ht.</u>	<u>COM</u>
<b><i>Bradley</i></b>					
5970 Series					
5971 Chair	43"	37"	26"	38"	9
5972 Loveseat	69"	37"	26"	38"	13
5973 Sofa	89"	37"	26"	38"	17

## SOFAS

<u>Style</u>	<u>Length</u>	<u>Depth</u>	<u>Arm Ht.</u>	<u>Back Ht.</u>	<u>COM</u>
<b><i>Dawson</i></b>					
3420 Series					
3421 Chair	32"	36"	23"	36"	6
3422 Loveseat	56"	36"	23"	36"	10
3423 Sofa	81"	36"	23"	36"	12

<u>Style</u>	<u>Length</u>	<u>Depth</u>	<u>Arm Ht.</u>	<u>Back Ht.</u>	<u>COM</u>
<b><i>Buckskin</i></b>					
7630 Series					
0820 Ottoman	31"	25"	--	18"	3
7631 Chair	37"	37"	26"	38"	7
7632 Loveseat	63"	37"	26"	38"	13
7633 Sofa	78"	37"	26"	38"	15
7635 Queen Sleeper	78"	37"	26"	38"	15

<u>Style</u>	<u>Length</u>	<u>Depth</u>	<u>Arm Ht.</u>	<u>Back Ht.</u>	<u>COM</u>
<b><i>Fairmont</i></b>					
3410 Series					
3411 Chair	33"	36"	25"	36"	7
3412 Loveseat	57"	36"	25"	36"	12
3413 (2) Cushion Sofa	81"	36"	25"	36"	14
34133 (3) Cushion Sofa	81"	36"	25"	36"	15

<u>Style</u>	<u>Length</u>	<u>Depth</u>	<u>Arm Ht.</u>	<u>Back Ht.</u>	<u>COM</u>
<b><i>Lehigh</i></b>					
9910 Series					
0820 Ottoman	31"	25"	--	17"	3
9911 Chair	37"	37"	26"	34"	8
9912 Loveseat	61"	37"	26"	34"	12
9913 Sofa	76"	37"	26"	34"	14
991378 Sofa	87"	37"	26"	34"	15
9915 Queen Sofa	78"	37"	26"	34"	14

## SOFAS

Style	Length	Depth	Arm Ht.	Back Ht.	COM
<b>Liberty</b>					
5700 Series					
0820 Ottoman	31"	25"	--	20"	3
5771 Chair	38"	37"	24"	34"	6
5772 Loveseat	62"	37"	24"	34"	10
5773 Sofa	81"	37"	24"	34"	11

Style	Length	Depth	Arm Ht.	Back Ht.	COM
<b>Magnolia</b>					
5870 Series					
0820 Ottoman	31"	25"	--	18"	3
5871 Chair	34"	37"	27"	35"	7
5872 Loveseat	57"	37"	27"	35"	9
5873 Sofa	81"	37"	27"	35"	12
5870U Chair Sleeper	74"	37"	27"	35"	11
5875 Queen Sleeper	81"	37"	27"	35"	12
5874 Full Sleeper	74"	37"	27"	35"	11

Style	Length	Depth	Arm Ht.	Back Ht.	COM
<b>Palmer</b>					
7290 Series					
0820 Ottoman	31"	25"	--	20"	3
7291 Chair	33"	36"	24"	33"	6.5
7292 Loveseat	60"	36"	24"	33"	10.5
7293 Sofa	84"	36"	24"	33"	12.5

Style	Length	Depth	Arm Ht.	Back Ht.	COM
<b>Pierson</b>					
9800S Series					
0510 Ottoman	34"	34"	--	19"	3
9802S Loveseat	69"	37"	30"	37"	12
9803S Sofa	84"	37"	30"	37"	13.5

## SOFAS

Style	Length	Depth	Arm Ht.	Back Ht.	COM
-------	--------	-------	---------	----------	-----

### *Butler*

#### 9970 Series

9971 Chair	43"	37"	26"	38"	9
9972 Loveseat	69"	37"	26"	38"	13
9973 Sofa	89"	37"	26"	38"	17

Style	Length	Depth	Arm Ht.	Back Ht.	COM
-------	--------	-------	---------	----------	-----

### *Becca*

#### 9930 Series

9931 Chair	38"	37"	30"	36"	8
9932 Loveseat	56"	37"	30"	36"	10
9933 Sofa	80"	37"	30"	36"	13

Style	Length	Depth	Arm Ht.	Back Ht.	COM
-------	--------	-------	---------	----------	-----

### *Lehigh II*

#### 9910 Series

9911 Chair	37"	37"	26"	34"	8
9912 Loveseat	61"	37"	26"	34"	12
9913 Sofa	76"	37"	26"	34"	14
9915 Queen Sleeper	78"	37"	26"	34"	14

Style	Length	Depth	Arm Ht.	Back Ht.	COM
-------	--------	-------	---------	----------	-----

### *Amanda*

#### 9800 Series

9802 Loveseat	69"	37"	30"	37"	12.5
9803 Sofa	84"	37"	30"	37"	13.5

Style	Length	Depth	Arm Ht.	Back Ht.	COM
-------	--------	-------	---------	----------	-----

### *Heidi*

#### 9620 Series

9621 Chair	34"	35"	28"	38"	7
9622 Loveseat	59"	35"	28"	38"	11.5
9623 Sofa	78"	35"	28"	38"	13
9624 Full Sleeper	71"	35"	28"	38"	11.5
9625 Queen Sleeper	78"	35"	28"	38"	13

## SOFAS

<u>Style</u>	<u>Length</u>	<u>Depth</u>	<u>Arm Ht.</u>	<u>Back Ht.</u>	<u>COM</u>
--------------	---------------	--------------	----------------	-----------------	------------

### ***Patti***

#### 9430 Series

9432 Loveseat	73"	36"	33"	37"	13
9433 Sofa	93"	36"	33"	37"	14

<u>Style</u>	<u>Length</u>	<u>Depth</u>	<u>Arm Ht.</u>	<u>Back Ht.</u>	<u>COM</u>
--------------	---------------	--------------	----------------	-----------------	------------

### ***Bridgewater***

#### 7760 Series

7762 Loveseat	78"	36"	32"	38"	13
7763 Sofa	93"	36"	32"	38"	15
7764 Full Sleeper	86"	36"	32"	38"	15
7765 Queen Sleeper	93"	36"	32"	38"	15

<u>Style</u>	<u>Length</u>	<u>Depth</u>	<u>Arm Ht.</u>	<u>Back Ht.</u>	<u>COM</u>
--------------	---------------	--------------	----------------	-----------------	------------

### ***Bailey***

#### 7610 Series

7613 Sofa	79"	40"	29"	39"	16
-----------	-----	-----	-----	-----	----

## SOFAS

Style	Length	Depth	Arm Ht.	Back Ht.	COM
<b><i>Austin</i></b>					
7410 Series					
7411 Chair	40"	36"	31"	34"	9
7412 Loveseat	58"	36"	31"	34"	11
7413 Sofa	82"	36"	31"	34"	15
7415 Queen Sleeper	82	36"	31"	34"	15

Style	Length	Depth	Arm Ht.	Back Ht.	COM
<b><i>Sydney</i></b>					
6200 Series					
6200 Ottoman	36"	23"	--	19"	3
6211 Oversized Chair	43"	35"	30"	40"	10
6213 Sofa	79"	35"	30"	40"	14

Style	Length	Depth	Arm Ht.	Back Ht.	COM
<b><i>Parker</i></b>					
5880 Series					
5881 Chair	38"	36"	25"	35"	6
5882 Loveseat	62"	36"	25"	35"	10
5883 Sofa	81"	36"	25"	35"	12
5884 Full Sleeper	74"	36"	25"	35"	11
5885 Queen Sleeper	81"	36'	25"	35"	12

Style	Length	Depth	Arm Ht.	Back Ht.	COM
<b><i>Manhattan</i></b>					
3440 Series					
3441 Chair	35"	36"	29"	33"	6
3442 Loveseat	59"	36"	29"	33"	9
3443 Sofa	83"	36"	29"	33"	11

## SOFAS

Style	Length	Depth	Arm Ht.	Back Ht.	COM
<b><i>Deluth</i></b>					
3210					
3211 Chair	39"	37"	30"	38"	7
3212 Loveseat	57"	37"	30"	38"	13
3213 Sofa	81"	37"	30"	38"	16
3215 Queen Sleeper	76"	37"	30"	38"	15

Style	Length	Depth	Arm Ht.	Back Ht.	COM
<b><i>Lindsey</i></b>					
2040 Series					
0820 Ottoman	31"	25"	--	17"	3
2041 Chair	40"	37"	27"	36"	9
2042 Loveseat	63"	37"	27"	36"	14
2043 Sofa	87"	37"	27"	36"	17
204360 Demi Sofa	78"	37"	27"	36"	15
2044 Full Sleeper	78"	37"	27"	36"	15
2045 Queen Sleeper	87"	37"	27"	36"	17